

Passive House, Zero Net Energy and Green building professionals have often struggled to find a simple and effective insulation panel to augment the exterior wall insulation on new or existing buildings, which is why Legalett Canada came up with the highly effective yet easy to use ThermalWall PH Panel.

The panels come in R-24, R-28 and R-32 configurations and install over any type of wall including ICF, wood, concrete, CMU or steel studs. If you need more insulation then your standard wall assembly provides, ThermalWall PH Panels are the ideal choice.

Find out more about ThermalWall here...





PASSIVEHOUSE CANADA Member

www.legalett.ca



Four Easy Steps



1. Place Panel



2. Screw the 4 corners first to position the panel



3. Install the rest of the screws





4. Installed Panel is ready for Snap Tracks

ThermalWall PH Panels can be strapped horizontally or vertically and can support any type of exterior siding or panelized finish systems.

Available in sizes: 1', 2' or 4' Wide x 8' Long

6" = R-24, 7" = R-28, 8" = R-32

Fasteners are included